



# Orbit Spaces

## Documentation File

Controlling Your Meeting  
Room Lights

# Documentation Details

<b>Date Written:</b>	22 <sup>th</sup> July 2024
<b>Author:</b>	Miles Waring
<b>Requirements:</b>	<ul style="list-style-type: none"><li>• You are in a meeting room that uses smart lighting</li></ul>

If you are experiencing any issues after following this help guide, please contact 01625 588200.

# Documentation Steps

1. Once inside an Orbit Spaces meeting room, locate the wireless smart light switch. ( *If you cannot locate the light switch, please find contact a member of staff.* )



*Wireless Smart Light Switch*

2. The wireless smart light switch is attached to the wall via a magnet, to remove it simply pull it off the wall.
3. The switch has 4 pre-programmed states labelled as 1,2,3,4. Click each one to change the light level in the room to the below levels:

Switch Button	Light Level (%)
1	100%
2	50%
3	25%
4	10%

4. If you require the lights changing to a different level than in step 3, use the '+' and '-' buttons to alter it by 1%.

# Troubleshooting

## **1. What if my wireless smart light switch does not work?**

If the switch is unresponsive to any commands, then please contact us on 01625 588200.

# ***Orbit***

S P A C E S